+ AUTODOC CLUB


How to change rear shock absorbers on **Mercedes W211** – replacement guide







VIDEO TUTORIAL



important!

This replacement procedure can be used for:

MERCEDES-BENZ E-Class Saloon (W211) E 220 CDI, MERCEDES-BENZ E-Class Saloon (W211) E 320 (211.065), MERCEDES-BENZ E-Class Saloon (W211) E 500 (211.070), MERCEDES-BENZ E-Class Saloon (W211) E 240 (211.061), MERCEDES-BENZ E-Class Saloon (W211) E 220 CDI (211.006), MERCEDES-BENZ E-Class Saloon (W211) E 270 CDI (211.016), MERCEDES-BENZ E-Class Saloon (W211) E 200 CDI (211.004), MERCEDES-BENZ E-Class Saloon (W211) E 55 AMG Kompressor (211.076), MERCEDES-BENZ E-Class Saloon (W211) E 200 Kompressor (211.076), MERCEDES-BENZ E-Class Saloon (W211) E 320 CDI (211.026), MERCEDES-BENZ E-Class Saloon (W211) E 400 CDI (211.028), MERCEDES-BENZ E-Class Saloon (W211) E 280 CDI (211.023), MERCEDES-BENZ E-Class Saloon (W211) E 280 CDI (211.023), MERCEDES-BENZ E-Class Saloon (W211) E 350 (211.056), (+ 11)

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1–16







REPLACEMENT: SHOCK ABSORBERS – MERCEDES W211. TOOLS YOU NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Torque wrench
- Combination spanner #16
- Combination spanner #17
- Drive socket # 18
- Torx bit T20

- Shock absorber socket #DD6
- Wheel impact socket #17
- Ratchet wrench
- Clip removal tool
- Hydraulic transmission jack
- Crow bar
- Flat Screwdriver
- Wheel chock

BUY TOOLS

CLUB.AUTODOC.CO.UK 2-16







Replacement: shock absorbers – Mercedes W211. AUTODOC experts recommend:

- Both shock absorbers of the rear suspension should be replaced simultaneously.
- The replacement procedure is identical for the left and right shock absorbers of the rear suspension.
- Please note: all work on the car Mercedes W211 should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1

Open the boot lid.



2

Unscrew the fastener of the boot side lining. Use a clip removal tool. Use Torx T20. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 3-16







Remove the clips of the boot side lining. Use a clip removal tool.



Remove the boot front lower lining.



Remove the clips from the plastic side panel. Use a flat screwdriver (2 pieces).



6 Detach the bulb connector.



Remove the side plastic cover.



CLUB.AUTODOC.CO.UK 4–16







8 Remove the boot side lining.



Clean the shock absorber fasteners. Use a wire brush. Use WD-40 spray.



Unscrew the upper fastener of the shock absorber. Use a combination spanner #17. Use a shock absorber socket #DD6. Use a ratchet wrench.



- 11 Secure the wheels with chocks.
- Loosen the wheel mounting bolts. Use wheel impact socket #17.



CLUB.AUTODOC.CO.UK 5-16







Raise the rear of the car and secure on supports.



14 Unscrew the wheel bolts.



AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
 Mercedes W211
- Remove the wheel.



Clean the shock absorber fasteners. Use a wire brush. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 6-16







Unscrew the lower fastener of the shock absorber. Use a combination spanner #16. Use a drive socket #18. Use a ratchet wrench.



18 Remove the fastening bolt.



AUTODOC recommends:

- Mercedes W211 To avoid injury, hold the shock absorber while unscrewing the fastening bolts.
- Support the shock absorber. Use a hydraulic transmission jack.



Remove the shock absorber. Use a crowbar.

20



CLUB.AUTODOC.CO.UK 7–16







AUTODOC recommends:

 Replacement: shock absorbers – Mercedes W211. Carefully inspect the mount, the boot, and the bump stop of the shock absorber. Replace if necessary.

21

Remove the hydraulic transmission jack.



AUTODOC recommends:

• Replacement: shock absorbers – Mercedes W211. Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.

22

Clean the shock absorber mounting seats. Use a wire brush. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 8-16







Replacement: shock absorbers – Mercedes W211. Tip from AUTODOC experts:

• Before installing a new shock absorber you should pump it manually 3-5 times.

23

Place the shock absorber in the wheel arch and secure it.



AUTODOC recommends:

- Mercedes W211 To avoid injury, hold the shock absorber while screwing in the fastening bolts.
- 24

Install the fastening bolt.



25

Support the control arm. Use a hydraulic transmission jack.



CLUB.AUTODOC.CO.UK 9-16







Screw in the lower fastener of the shock absorber. Use a combination spanner #16. Use a drive socket #18. Use a ratchet wrench.



Tighten the lower fastener of the shock absorber. Use a combination spanner #16. Use a drive socket #18. Use a torque wrench. Tighten it to 55 Nm torque.



Remove the support from under the control arm.



AUTODOC recommends:

 Replacement: shock absorbers – Mercedes W211. Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.

CLUB.AUTODOC.CO.UK 10-16







Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



Clean the brake disk surface. Use a brake cleaner.



AUTODOC recommends:

 Replacement: shock absorbers – Mercedes W211. After applying the spray, wait a few minutes.

31

Install the wheel.



AUTODOC recommends:

• Important! Hold the wheel while screwing in the fastening bolts. Mercedes W211

CLUB.AUTODOC.CO.UK 11-16







Screw in the wheel bolts. Use wheel impact socket #17.



Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 130 Nm torque.



Remove the jacks and chocks.



Tighten the top shock absorber fastening. Use a combination spanner #17. Use a shock absorber socket DD№6. Use a torque wrench. Tighten it to 20 Nm torque.



CLUB.AUTODOC.CO.UK 12-16







Treat the shock absorber fasteners. Use copper grease.



Attach the side lining of the boot.



Install the clips of the boot side lining.



Screw in the fastener of the boot side lining. Use Torx T20. Use a ratchet wrench.



40 Attach the bulb connector.



CLUB.AUTODOC.CO.UK 13-16








Install the side plastic panel.



Reinstall the clips of the plastic side panel.



Install the boot front lower lining.

44



Close the lid of the luggage compartment.



WELL DONE!


VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 14-16





AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR MERCEDES

SHOCK ABSORBERS: A WIDE SELECTION

CLUB.AUTODOC.CO.UK 15-16







SHOCK ABSORBERS FOR MERCEDES: BUY NOW

SHOCK ABSORBERS FOR MERCEDES W211: THE BEST DEALS & OFFERS

① DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.

CLUB.AUTODOC.CO.UK 16-16